



## Electric Kettle

**Overall Size:** 12 Quart Capacity

1250 Watt heating element provides efficient heating of room temperature, refrigerated or frozen food products. It can be used wet or dry.

### **Cautions:**

**Do not run an empty kettle on "HI"**

**Reduce heat as product is emptied from the kettle to avoid scorching reduced volume of product.**

**Always turn the kettle "OFF" when not in use.**

### **Operating Procedure:**

1. **Plug in** kettle and **rotate temperature knob** to desired setting. A pilot light will glow amber when unit is on.
2. **Wet operation** recommended for most preparation and serving situations
  - a) **Add 24 ounces** of water between the food insert and the kettle insert for the 12 quart kettle.
  - b) To rapidly heat product, set switch to **"HI"**. When desired temperature is reached, **set** switch **3** and **4**. If product **boils**, set switch on **"LOW"** until serving temperature is reached. Set between 3 and 4 to **Hold** or **Serve**.
3. **Dry Operation**
  - a) **During serving conditions** (e.g., the cover being opened frequently) to maintain product at about 165°F (74°C) the **Temperature control knob should be set at 5**.
  - b) **During holding conditions**, (.g., the cover closed with long intervals between servings) to maintain product at about 165°F(74°C) the **temperature control knob should be set between 3 and 4**.