



Punch Fountain

This fountain will hold a maximum of five gallons

Pour your punch into the bowl of the fountain. The on /off switch is at the base of the fountain.

The punch will be pumped up through the center of the fountain. If the flow is not satisfactory, the screw on the top should be turned to either increase or decrease the flow of liquid.

The fountain **will not** keep your punch cold. Please note that if your punch contains fruit pulp or like material, this may clog the pump.

The fountain needs a minimum of approximately one gallon of liquid to operate.